

1520-...

WORKSHOP CALIPER

- for inside, outside measurement
- reading by vernier scale 0,05 mm respectively 1/128"
- with stepped jaws, knife points and locking screw
- matt chrome plated reading parts
- thread table on the back
- stainless steel
- DIN 862



Code	Number	Measuring range mm	Measuring range Inch	Jaws mm	Jaws Inch	Pieces	Weight/g
1520002002000	1520-200	200	8	80	3,2	1	519
1520002502000	1520-250	250	10	80	3,2	1	610
1520003002000	1520-300	300	12	90	3,5	1	687

1522-300

WORKSHOP CALIPER

- in case
- for inside, outside measurement
- reading by vernier scale 0,05 mm respectively 1/128"
- with stepped jaws, knife points, fine adjustment and locking screw
- matt chrome plated reading parts
- thread table on the back
- stainless steel
- DIN 862



Code	Number	Measuring range mm	Measuring range Inch	Jaws mm	Jaws Inch/Inch	Pieces	Weight/g
1522003001000	1522-300	300	12	100	4	1	761

1515-...

PRECISION DIAL CALIPER

- in plastic case
- for inside, outside and depth measurement (4 way measurement)
- 1515-50: reading 0,02 mm
- 1515-100: reading 0,01 mm
- jaw length 40 mm respectively 1,57 inch
- fine adjustment scroll, locking screw
- stainless steel
- DIN 862



Code	Number	Measuring range mm	Measuring range Inch/Inch	Reading mm	Pointer Rotation mm	Pieces	Weight/g
1515000500000	1515-50	150	6	0,02 = 1/50	2	1	388
1515001000000	1515-100	150	6	0,01 = 1/100	1	1	373