

Internal Extractor Kit

09450000

Kit Contents:

DESCRIPTION	REF
Beam	09311200
Force Screw	09311300
Thrust Nut	09311400
Thrust Race	09312100
Main Rods	09311500
Protectors	09312000
Leg Assembly	09351400
Extractor Beam	09351200
Extractor Adj. Screw	09351500



For applications requiring an internal pulling action. The Internal extractor kit can be used on its own, where no other pullers are available.

The Internal pulling attachments are for use with either the mechanical or hydraulic separator kits. Individual separators can be used with any of the Sykes-Pickavant designs of pullers, where standard puller legs cannot gain access.

Internal Pulling Attachment

09350000


- For use with Mechanical Separator Kits 09310000 or 09320000
- If using 09350000 with kit ref 09320000, Screw Adaptor 09350100 is required

Internal Pulling Attachment

09360000

- For use with Mechanical Separator Kits 09330000
- Screw Adaptor 09360100 is required

REFERENCE	INTERNAL DIAMETER CAPACITY		REACH		USE WITH SEPARATOR KIT REF.	SCREW ADAPTOR REQUIRED
	ins	mm	ins	mm		
09350000	1 1/2 - 6	40 - 150	4	100	09310000 09320000	NONE 09350100
09360000	3 - 9	75 - 230	5 7/8	150	09330000	09360100



Individual Bearing Separators

- Can be used with any of the Sykes-Pickavant design of pullers, where standard puller legs cannot gain access.
- Tapered edges provide all round support

REFERENCE	CAPACITY		USE WITH 2 LEG MECHANICAL PULLER	USE WITH 2 LEG HYDRAULIC PULLER
	ins	mm		
09500000	0 - 2 1/4	0 - 55	08300000 09300000	
09510000	3/4 - 4 1/4	20 - 105	08310000 09310000	1500 Series 19310000
09520000	1 1/4 - 5 1/2	35 - 140	08320000 08330000 09320000	1500 Series 19320000
09530000	2 - 7	50 - 175	09300000	Loadstar Series



09520000



09510000



09500000

Combination Separator / Puller Kits

Refer to page 12 - 13 for details of Combination Separator & Puller Kits - both mechanical and hydraulic options